



## FujiMAC Air Pump spare parts list

No.	Model R	Model R II	Item Name	Part No.	Qty	Order per Air pump
1-1	MAC40R	MAC40R II	N6 DIAPHRAGM ASSEMBLY	H150K	2pcs/set	1set
	MAC60R					
1-2	MAC80R		N8 DIAPHRAGM ASSEMBLY	H151K	2pcs/set	1set
	MAC100R					
	MAC120R					2set
	MAC150R					
	MAC200R					
1-3		MAC60R II	T10 DIAPHRAGM ASSEMBLY	H154K	2pcs/set	1set
		MAC80R II				
		MAC100R II				2set
		MAC150R II				
		MAC200R II				
1-4		MAC120R II	T30 DIAPHRAGM ASSEMBLY	H157K	2pcs/set	1set
		MAC250R II				2set
		MAC300R II				
2-1	MAC40R	MAC40R II	N6 AIR FILTER(WHITE)	H507	1pcs	1pcs
	MAC60R					
2-2		MAC60R II	N8 AIR FILTER(WHITE)	H508	1pcs	1pcs
	MAC80R	MAC80R II				
	MAC100R	MAC100R II				
		MAC120R II				2pcs
	MAC120R					
	MAC150R	MAC150R II				
	MAC200R	MAC200R II				
		MAC250R II				
	MAC300R II					